




AHE-100-04S - 12 VDC

AHE-130-04X - 12 VDC

PARTS MANUAL

Table of Contents

AHE-100-04S and AHE-130-04X Models

Diesel Burner Parts	Page 5-7
Diesel Burner and Fuel Lines	Page 8
Heating Zone Plumbing	Page 9
Engine Preheat Plumbing	Page 10
Domestic Water Plumbing	Page 11

AHE-100-04S Model (Only)


Electrical Components, Internal	Page 12
Electronic Controller and Switch Panel	Page 13

AHE-130-04X Model (Only)


Electrical Components, Internal	Page 14
Electronic Controller and Switch Panel	Page 15

Section 3: Misc. Tools & Parts


Misc. Tools	Page 16
Misc. Parts	Page 17



Key	Part Number	Description
2	WPX-287-962	Controller, Diesel Burner, 12 VDC
3	WPX-362-107	Bracket, Controller Mounting
4	WPX-470-562	Screw, Coil Mounting
5	WPX-101-838	Coil, Ignition, 12 VDC
6	WPX-404-918	Boot, Ignition Wire
7	WPX-178-624	Wire, Ignition
8	WPX-176-494	Boot, Ignition Wire, Elbow
10	WPX-350-427	Shutter, Combustion Air Intake
11	WPX-432-377	Screw, Protection Housing
12	WPX-152-269	Washer, Star, Protection Housing
14	WPX-436-216	Cap, Protection, Motor
22	WPX-147-834	Screw, Flange, Blower Housing
24	WPX-425-05A	Plate, Motor Mounting
25	WPX-432-377	Screw, Motor Plate
26	WPX-152-269	Washer, Star, Motor Plate
27	WPX-425-060	Motor, Combustion Air/Fuel Pump, 12 VDC
28	WPX-350-516	Clutch, Half, 6mm




Key	Part Number	Description
35	WPX-434-795	Harness, C-Plug
38	WPX-148-210	Screw, Blower Casting
39	WPX-152-552	Washer, Lock, Blower Casting
40	WPX-301-841	Housing, Blower
41	WPX-373-001	Blower, Wheel, w/Shaft
42	WPX-378-313	Bearing Kit
43	WPX-412-244	O-Ring, Blower Casting
44	WPX-225-67A	Casting, Blower
45	WPX-298-964	Grommet, Blower Casting, Left
46	WPX-299-995	Grommet, Blower Casting, Right




Key	Part Number	Description
50	WPX-322-083	Valve, Fuel Solenoid, 12 VDC
51	WPX-386-650	Valve, Fuel Solenoid, Kit
52	N/A	
53	WPX-267-279	Bolt, Electrode
54	WPX-152-560	Washer, Lock, Electrode
55	WPX-278-971	Clamp, Electrode
56	WPX-274-313	Electrode, Ignition
58	WPX-147-699	Screw, Flame Sensor
59	WPX-638-78A	Sensor, Flame
60	WPX-453-048	Clip, Retaining, Photo Disc
61	WPX-887-71A	Disc, Photo
62	WPX-503-03A	Pump, Fuel, Kit
65	WPX-665-49A	Tube, Fuel, High Pressure
66	WPX-150-754	Bolt, Banjo
67	WPX-151-157	Gasket, Ring, Copper
68	WPX-661-002	Pipe, Fuel, Banjo, Supply, DBW 2010 (w/Straight Tube)
69	WPX-661-001	Pipe, Fuel, Banjo, Return, DBW 2010 (w/Straight Tube)
70	WPX-277-282	Screw, Mounting, Fuel Pump
71	WPX-152-544	Washer, Lock, Fuel Pump
72	WPX-886-41A	Nozzle, Fuel, 0.35 GPH
73	WPX-412-198	Stand, Fuel Nozzle, Brass
74	WPX-277-150	Screw, Plate, Nozzle Stand
75	WPX-102-861	Plate, Manifold
76	WPX-371-289	Gear, Fuel Pump, Nylon
77	WPX-152-390	Snap, Ring, Gear
78	FLE-FUL-100	Fuel Kit, JIC, Male, w/Nut & Ring, Complete

DIESEL BURNER AND FUEL LINES




Key	Part Number	Description
1	PLX-105-800	Fitting, Bulkhead, 3/4 (M) NPST x 1/4 in (F) NPT, Brass
2	FLX-751-CVL	Valve, Check, Fuel 1/4 in (M) NPT
3	FLX-FL1-022	Fitting, Elbow, 1/4 in (F) NPT
4	FLX-038-204	Fitting #6 (M) JIC x 1/4 in (M) NPT
5	FLE-FUL-200	Hose, Fuel, Supply/Return Kit w/Clamps
6	FLE-FUL-100	Fitting, Fuel Line, Hose Barb x Compression
7	WPX-310-646	Gauge, Adjustment, Electrode
8	WPX-461-555	Bolt, Eye
9	WPX-420-565	Pin, Eye Bolt
10	WPX-363-618	Nut, Eye Bolt
11	PLE-688-002-FRU	Valve, Ball Assembly
12	WPX-265-53A	Chamber, Combustion
13	FLX-131-280	Fitting, Elbow, #6 (M) JIC x 1/4 in (M) NPT
14	WPE-905-834	Burner, Diesel, 12 VDC

HEATING ZONE PLUMBING




Key	Part Number	Description
1	PLE-100-811	Pump, Circulation, Kit
2	PLX-699-330	Fitting, 1/2 in Hose Barb x 1/2 in (M) NPT
3	PLX-2A1-300	Valve, Check, 1/2 in (F) NPT
4	PLE-100-500	Manifold, Zone Return
5	PLX-A65-800	Fitting, Elbow 45°, 3/4 in Hose Barb x 1/2 in (M) NPT

ENGINE PREHEAT PLUMBING




Key	Part Number	Description
1	PLX-105-810	Fitting, Bulkhead, 3/4 in (M) NPST x 1/2 in (F) NPT
2	PLX-699-330	Fitting, 1/2 in Hose Barb x 1/2 in (M) NPT
3	PLE-100-811	Pump, Circulation, Kit




Key	Part Number	Description
1	PLX-09P-100	Valve, Tempering
2	PLX-111-125	Valve, Pressure Relief

ELECTRICAL COMPONENTS, INTERNAL (AHE-100-04S ONLY)




Key	Part Number	Description
1	SME-101-201	Cover, Access, Thermostat
2	ELX-630-001	Relay, Electromechanical
3	ELE-ASY-300-FRU	Thermostat, High-Limit, VAC, Kit, w/Connector
4	ELE-HLT-322	Thermostat, High-Limit, VDC
5	ELE-014-005	Thermostat, Control, 185°F, 1/2 (M) NPT
6	ELE-800-002	Switch, Float, Assembly
7	SME-200-200	Cover, Access, Junction Box
8	ELX-002-100	Meter, Hour, Quartz
9	ELX-2E7-540	Element, Heating, 120 VAC, 1650 Watts
10	SME-200-301	Cover, Access, Heating Element.

ELECTRONIC CONTROLLER AND SWITCH PANEL (AHE-100-04S ONLY)




Key	Part Number	Description
1	SME-200-501	Faceplate, Electronic Controller, Assembly, Enclosure
2	ELX-312-491	Plug, Electronic Controller, 20-Position
3	ELX-312-499	Plug, Electronic Controller, 8-Position
4	ELE-PC4-010-AA	Controller, Electronic w/Time Delay, 12 VDC
5	ELE-100-453	Harness, Control
6	ELE-100-422	Harness, B-Plug
7	SME-EN4-008	Back, Electronic Controller, Enclosure
8a	ELE-000-507	Panel, Switch, Assembly, 12 VDC (Discontinued)
8b	ELE-000-509	Panel, Switch, Assembly, 12 VDC
9a	ELX-283-284	Switch, Rocker, w/LED (Discontinued)
9b	ELX-283-283	Switch, Rocker, w/LED

ELECTRICAL COMPONENTS, INTERNAL (AHE-130-04X ONLY)




Key	Part Number	Description
1	SME-101-201	Cover, Access, Thermostat
2	ELX-630-001	Relay, Electromechanical
3	ELE-ASY-300-FRU	Thermostat, High-Limit, VAC, Kit, w/Connector
4	ELE-HLT-322	Thermostat, High-Limit, VDC
5	ELE-800-100	Thermostat, Control, 190°F, Assembly
6	ELE-800-002	Switch, Float, Assembly
7	ELX-002-100	Meter, Hour, Quartz
8	SME-200-200	Cover, Access, Junction Box
9	ELX-G12-07L	Element, Heating, 120 VAC, 2000 Watts
10	SME-200-301	Cover, Access, Heating Element.


ELECTRONIC CONTROLLER AND SWITCH PANEL (AHE-130-04X ONLY)



Key	Part Number	Description
1	SME-200-501	Faceplate, Electronic Controller, Assembly, Enclosure
2	ELX-312-491	Plug, Electronic Controller, 20-Position
3	ELX-312-499	Plug, Electronic Controller, 8-Position
4	ELE-PC4-010-AA	Controller, Electronic w/Time Delay, 12 VDC
5	ELE-100-463	Harness, Control
6	ELE-100-422	Harness, B-Plug
7	SME-EN4-008	Back, Electronic Controller, Enclosure
8a	ELE-000-907	Panel, Switch, Assembly, 12 VDC (Discontinued)
8b	ELE-000-908	Panel, Switch, Assembly, 12 VDC
9a	ELX-283-284	Switch, Rocker, w/LED (Discontinued)
9b	ELX-283-283	Switch, Rocker, w/LED



Key	Part Number	Description
1	WPX-440-280	Tester, Controller
2	WPE-600-190	Gauge, Fuel Pressure
3	MSX-907-162	Tester, Refractometer, Battery/Coolant
4	WPX-310-646	Gauge, Adjustment, Electrode



Key	Part Number	Description
1	MSX-300-275	Antifreeze, Boiler, P.G., 1 qt, Concentrate, (Camco)
2	MSX-300-270	Antifreeze, Boiler, P.G, 1 Gallon (Camco)
3	FLX-R12-TRA	Filter, Fuel, Racor Spin-On, 10 Micron
4	FLE-120-100	Filter, Canister, Replacement, Garber
5	FLX-120-000	Filter, Fuel, Garber
6	WPX-265-53A	Combustion Chamber, DBW 2010
7	WPX-303-051	Swirler, Combustion Chamber Air Assembly Cast Aluminum
8	WPX-302-651	Air Swirler, DBW 2010
9	WPX-303-050	Tube, Combustion Chamber, DBW 2010
10	PLX-102-229	Cap, Radiator, 13 lb
11	PLE-GAS-FLL	Gasket, Rubber, Filler Neck



AHE-100-04S

AHE-130-04X

PARTS MANUAL